NOTOMI

# Noto Link Flex CB–6

INSTRUKCJA OBSŁUGI
USER MANUAL

PL

## Noto Link Flex CB–6

KABEL USB

**Informacje o produkcie:**

- Długość kabla: 1,2 m
- Typ złącza: USB-C do Lightning
- Materiał: silikon
- Kolor: biały

**Specyfikacja:**

- Maksymalna moc ładowania: 60 W (20 V/3 A)
- Standard: USB 2.0

**Ładowanie:**

1. Podłącz wtyk USB-C do zasilacza sieciowego.
2. Drugi koniec kabla podłącz do urządzenia (np. tablet, smartfon).
3. Upewnij się, że ładowarka i urządzenie obsługują wymagane parametry (20 V/3 A), aby uzyskać pełną moc.

**UWAGA!**

1. Nie zginać kabla pod ostrym kątem, unikać nadmiernego naciągania.
2. Nie wystawiać na działanie wody, deszczu ani wysokiej wilgotności.
3. Nie demontować, nie modyfikować ani nie naprawiać urządzenia we własnym zakresie.
4. Nie używać w pobliżu źródeł ciepła ani ognia.
5. Nie używać kabla, jeśli jest uszkodzony, przegrzewa się lub widać odsłonięte przewody.
6. Urządzenie nie jest zabawką – trzymać poza zasięgiem dzieci.
7. Nie ładować w temperaturze poniżej 0°C ani powyżej 40°C.
8. Nie wyrzucać kabla do odpadów komunalnych.

**Prawidłowa utylizacja zużytego sprzętu:**

Produkt oznaczony jest symbolem przekreślonego kosza na śmieci. Zgodnie z Dyrektywą WEEE (2012/19/UE) sprzęt elektryczny i baterie nie mogą być traktowane jako odpad komunalny. Należy je przekazać do odpowiedniego punktu zbiórki odpadów elektrycznych i elektronicznych w celu właściwego przetworzenia i recyklingu.

CE Notomi Polska Sp. z o.o. niniejszym deklaruje, że produkt spełnia zasadnicze wymagania oraz stosowne przepisy właściwych dyrektyw UE dotyczących bezpieczeństwa i zgodności.

**Producent:**

Notomi Polska Sp. z o.o.
ul. Czerniakowska 87A
00-718 Warszawa, Polska
www.notomi.com
mail: biuro@notomi.com

Wyprodukowano w Chinach.
Zaprojektowano w Polsce.

EN

# Noto Link Flex CB–6

USB CABLE

**Product information:**

- Cable length: 1.2 m
- Connector type: USB-C to Lightning
- Material: silicone
- Color: white

**Specifications:**

- Maximum charging power: 60 W (20 V/3 A)
- Standard: USB 2.0

**Charging:**

1. Connect the USB-C connector to a power adapter.
2. Connect the other end of the cable to your device (e.g., tablet, smartphone).
3. Make sure the charger and device support the required parameters (20 V/3 A) to achieve full power.

**WARNING!**

1. Do not bend the cable at sharp angles and avoid excessive stretching.
2. Do not expose it to water, rain, or high humidity.
3. Do not disassemble, modify, or repair the device yourself.
4. Do not use near heat or fire.
5. Do not use the cable if it is damaged, overheats, or has exposed wires.
6. This device is not a toy – keep out of the reach of children.
7. Do not charge at temperatures below 0°C or above 40°C.
8. Do not dispose of the cable in municipal waste.

**Correct disposal of used equipment:**

This product is marked with the crossed-out wheelie bin symbol. According to the WEEE Directive (2012/19/EU), electrical equipment and batteries should not be treated as municipal waste. They should be taken to an appropriate collection point for electrical and electronic waste treatment and recycling.

CE Notomi Polska Sp. z o.o. hereby declares that the product complies with the essential requirements and applicable provisions of the relevant EU directives regarding safety and compliance.

**Manufacturer:**

Notomi Polska Sp. z o.o.
ul. Czerniakowska 87A
00-718 Warsaw, Poland
www.notomi.com
mail: biuro@notomi.com

Made in China.
Designed in Poland.